

SkyBest TV

Picture Resolution Instructions

Having trouble seeing the guide? Try resetting the Picture Resolution to correct the problem.

- Press the small **“Green”** button on your SkyBest TV remote control
 - This is located just above the Volume button
- Then press the **“1”** button – This will set your resolution to 480i (RF Mod Channel 3) (SDTV)

OR

- Press the small **“Green”** button on your SkyBest TV remote control
- Then press the **“2”** button – This will set your resolution to 480i (RF Mod Channel 4) (SDTV)

OR

- Press the small **“Green”** button on your SkyBest TV remote control
- Then press the **“3”** button – This will set your resolution to 480p (EDTV)

OR

- Press the small **“Green”** button on your SkyBest TV remote control
- Then press the **“4”** button – This will set your resolution to 720p (HDTV)

OR

- Press the small **“Green”** button on your SkyBest TV remote control
- Then press the **“5”** button – This will set your resolution to 1080i (HDTV)